

**Rear Spar Attachment
Drilling Hole Layout
6T2-3**

Just cut out the box above and tape to rear spar attachment.

This template is provided to help aid fellow builders in making the 601HD(s) stabilizer. You use this template at your own risk!!! Verify with plans before using!